



Decoder installation:

- Remove the tender body from the tender chassis board.
- Connect the decoder wires directly to the main board.

JOIN NO. ON PCB	1	2	4	5	6	7	8
WIRING TO:	MOTOR	REVERSE LIGHT	POWER LEFT	MOTOR	FORWARD LIGHT	COMMON LIGHT	POWER LIGHT
WIRE COLOR	ORANGE	YELLOW	BLACK	GREY	WHITE	BLUE	RED