


Instructions to Repair Bachmann On30 Climax Gears

Below are the parts you will receive.




Turn the Climax over and gently pull off the trucks.

- 1) Remove the three screws (red lines) and keep in a safe place.
- 2) Slide the brakes back to release the bar that connects the brakes on the side that covers the drive line (blue arrows).
- 3) Remove the bar (green arrow).



Replace all of the gears indicated by the red lines. Replace any drive lines that have cracked gears.



Lube with gear oil as needed.

Replace the gear cover and three screws.

Replace the bar between the brake beams.

Reconnect the trucks to the drive line and snap the trucks in place making sure the electrical contacts on the trucks touch the contact pads on the engine.