



JOIN NO. ON PCB	1	2	4	5	6	7	8
WIRING TO :	MOTOR +	REVERSE LIGHT	POWER LEFT	MOTOR -	FORWARD LIGHT	LIGHT COMMON	POWER RIGHT
WIRE COLOR	ORANGE	YELLOW	BLACK	GREY	WHITE	BLUE	RED

"N" SCALE DCC WIRING INSTRUCTION

**S258X INSTRUCTION**

- (1) To open the body shell
  - a. Remove the couplers by unscrewing the coupler screw.
  - b. Remove the body shell by gently pulling the bottom sides out and lifting the shell.
- (2) For digital command control (D.C.C) use (optional).
  - a. After remove the body shell (see instruction(1)).
  - b. Simply remove the dummy plugs and install the D.C.C compatible decoder(see diagram A).